



## Ecotex® Revolutionmat : Selection, Use & Care

Floor mats are highly cost-effective in protecting expensive floor coverings from loss of appearance, wear and damage. There is a wide selection of shapes to suit user requirements. They have an embossed upper surface, and are usually translucent so that the appearance of the underlying floor covering remains visible.

In addition to facilitating easier movement of office chairs, particularly on carpeted floors, they can also be used on any flooring area needing protection, such as under areas used by pets, childrens' high chairs, and indoor pot plants.

### Selection:

**Smooth Back with Anti-Slip** - suitable for all flat and even hard floor surface. Also suitable for very low pile / no pile carpets where grippers would be unable to penetrate.

**Gripper Back** - Designed for use on low pile carpets up to 1/4" thick including padding.

### Please note:

- Use spiked mats on carpeted floors only: spiked mats will damage wooden floors: all spiked mats will be damaged by castor chairs if used on hard floors.
- Use smooth back anti-slip mats on all hard floors, including high gloss or polished wooden floors, to prevent slippage.
- Mats suitable for short pile carpets are unsuitable for use on deep pile carpets: they will crack due to lack of support.

### Use and care:

Correct use and care of your floor mat will ensure its serviceability and durability as well as giving best protection for your floor covering.

- If your mat was supplied folded, unfold and place on the floor with the grippers (carpet format) or smooth side (anti-slip) facing your flooring. The lightly textured side should face upwards.
- If your mat does not go instantly flat, re-fold it two or three times along the crease - in both directions - and re-lay it in the unfolded flat position on the floor.
- In some environments the mat may still take a short period of time to totally flatten depending on the room temperature. This should not take more than a few hours.
- Placing weighted objects on top of the mat will speed up any flattening that is required. To avoid a trip hazard, we recommend not putting your chair mat in to full application until the mat is completely flat.
- As with any household or office product, handle with care at all times to maintain quality and durability.
- Floor mats are precision cut to size: do not cut or in any way alter mats as this can impair performance.
- Do not use in wet areas.
- Do not use where there are extremes of temperature.
- Do not subject mats to excessive concentrated loads.
- Do not use floor mats under office chairs which have metal castor wheels.
- Clean only with a cloth or sponge soaked in mild soapy water.
- Do not use smooth floor mats on ridged, pitted or uneven concrete as they will be damaged by office chair loadings.
- Floors with rough textured floor tiles, or deep or wide grooves between tiles will damage mats under office chairs.